

## NOTES:

SMOOTH, CLEAN AND LEVEL BEARING SURFACES ARE REQUIRED FOR PROPER PLANK INSTALLATION. WALLS TO BE BE FURNISHED AND INSTALLED BY CUSTOMER OR THEIR GENERAL CONTRACTOR, NOT BOCCELLA. NO WALLS, PIPES, CONDUIT OR OTHER FIXTURES ARE TO EXTEND ABOVE THE PRECAST BEARING SURFACE UNTIL THE PLANKS HAVE BEEN SET INTO THEIR FINAL DESIGNED POSITION.

June 2009



## Boccella Precast, LLC

324 New Brooklyn Road Berlin, New Jersey 08009

Phone: (856) 767-3861 Fax: (856) 767-7228 www.boccellaprecast.com

## STANDARD DESIGN CATALOG

DRAWING DESCRIPTION:

TYPICAL SIDE LAP CMU WALL EXTERIOR WALL

SCALE:

CATALOG:

3/4" = 1'-0"

PAGE 3